

## HOW TO ROLL OUT THE AWNING


1. Loosen black knobs.




2. Release black lugs by pushing towards the van.



3. Using the extension arm move the release lever to the 'Down' position and awning will unroll – Unroll awning to desired length.



4. Slide up support stays until they 'lock' in place.



5. Release handle and extend awning and lock back into place using the locating pins.



6. Apply a small amount of down-ward pressure to the angled stay to tighten awning then secure by tightening the black knob.

