

OPERATION OF THE TOILET

1. Open the lid of the toilet and give it a small flush. This is done by pushing the button on top of the system.



2. Open the waste flap by sliding the handle as pictured below. Note: Please do not pull on the handle as this will cause the handle to snap off. When finished using the toilet, flush once again by pressing the button, this will allow the waste to be captured by the holding tank below. Once all waste has been flushed down close the storage flap by sliding the handle back to its original position.



- To empty the storage container, open the side storage compartment door with the caravan key. Remove the storage container by lifting the orange handle. Note: If the container does not come out easy it will mean the flap from the toilet to the container is open. This must be closed from the inside by sliding the handle across as per Step 2. Remove the container and take to a suitable dump point. Once at the dump point pivot out the orange spout and remove the lid ensuring not to lose the lid. Pour contents out while pushing the orange button at the rear of the container, by pushing the button it allows air into the container to prevent splash back.



- Preparing of the toilet for use once emptied. Locate the toilet chemical stored in the front storage area. Open the door of the flushing tank compartment using the caravan key. Pour 100mls of chemical from bottle marked with 'Flush Chemical Top Compartment' into the top filling tank. This can be measured by using the lid from the storage container. Once chemical has been placed in the storage compartment then fill with water to the top. Close and lock the door.



- Pour 100mls of chemical from bottle marked with 'Flush Chemical Catch Tank' This can be measured by using the lid from the storage container. Once chemical has been placed in the Catch Tank it can now be placed back in the storage compartment. Shut the door of the storage compartment and return chemical to front caravan storage area. **You're done!!!!!! Time to wash your hands.**